

# APEX V1 BOARD QUICK SET UP GUIDE

## BY REMOVING THIS DOCUMENT AND ASSEMBLING THIS PRODUCT YOU ARE AGREEING TO THE FOLLOWING TERMS AND CONDITIONS:

- The user understands that use of this product and any of its components involves certain inherent risks, dangers and hazards that can result in serious injury and death.
- The user has read, fully understands, and agrees to be bound by the terms of the Ozone product manual including the Release of Liability, Claim Waiver, Assumption of Risk Agreement, Warnings and Safety Precautions.
- Any and all users of this product must fully understand and agree to these terms.

IF YOU ARE UNWILLING TO BE BOUND BY THESE TERMS, KEEP THIS DOCUMENT IN TACT AND RETURN THIS PRODUCT (BEFORE USE) FOR A FULL REFUND.

## IMPORTANT NOTES:

- Before assembling check all connecting surfaces, screws and barrel nuts are clean and free of sand, salt or other debris.
- Only use original Ozone screws, t-nut deck washers and barrel nuts. Damage and/or loss may occur if using another type of hardware.
- Do not tighten screws until all screws are in position and correctly threaded.
- Do not over tighten the screws, firmly hand tighten (approx. 8N.m torque wrench setting) and release screws by hand only. Do not use power tools.
- If stored set up, before each use check the screws and parts are fitting tight, retighten screws if necessary.

# OZONE®

## BOARD

Apex V1



## MOUNTING HARDWARE:

4x Custom Titanium T-Nut Deck Washers

## MAST

4x T30 24mm Custom Titanium Screws.

**NOTE:** You must use 24mm screws supplied with the Apex V1 board to mount the Apex V1 Mast.

## MAST TO BOARD:

TO MOUNT AN OZONE MAST TO THE APEX V1 BOARD USE THE SUPPLIED 4X T30 24MM CUSTOM TITANIUM SCREWS AND CUSTOM TITANIUM T-NUT DECK WASHERS.

- 1: Fit the 4x T-Nut Deck Washers into the board slots.
- 2: Fit the 4x T30 24mm Custom Titanium Screws into the T-Nut Deck Washers. Turn each screw one full rotation to get the thread started.
- 3: Slide the screws and washers to the ends of the board slots.
- 4: Place the mast on the board and align the slots.
- 5: Slide each screw into the slot on the mast, ensuring the T-Nut Deck Washers remain connected.
- 6: Slide the screws until they fit at the countersunk section of each slot on the mast.
- 7: Firmly hand tighten each screw (approx. 8N.m torque wrench setting)

**Note:** to mount another brand mast you may need a different screw configuration. Consult your shop/dealer for assistance.



VIEW ONLINE MANUAL