

POCKET ROCKET maintenance GUIDE

REPAIRING TIP TEARS BETWEEN B & C BRIDLE TABS:

- 1:** Take the white sticky rip stop fabric from the repair kit that gets supplied with the Pocket Rocket.
- 2:** Cut a approximately 3-5cm wide strip off it and cut to length of distance between B and C tab
- 3:** Round off the edges
- 4:** Lay the rib onto a flat surface
- 5:** Apply the sticky rip stop strip onto the rib between the tabs
- 6 & 7:** Use the back of the scissors to rub the sticky rip stop onto the rib fabric to create a strong bond
- 8:** Cut out the excess stick rip stop material along the arc of rib
- 9:** Done - get back on the water!

