

C4 V6 BRIDLE CHECK SHEET

CHECKING BRIDLES FOR STRETCH OR SHRINKAGE

WE RECOMMEND YOU REGULARLY CHECK YOUR KITES BRIDLES TO KEEP YOUR KITE FLYING AT TOP PERFORMANCE. USE THE MEASUREMENTS TO CHECK YOUR BRIDLE LENGTHS.

RECOMMENDATIONS

- Open your kite in a large space, big enough to spread your kite out fully.
- Use a tape measure to measure the bridles.
- Print out the sheet and write down any differences.

If your bridles are out by more than 15mm we recommend replacing them, please get in touch with the shop/dealer you purchased the kite from and they can order individual bridle lines or a full set if they do not already have stock.

C4 V6 BRIDLE CHECK SHEET. ALL MEASUREMENTS IN MM

LINE NUMBER	SIZE							
	6M	7M	8M	9M	10M	11M	12M	14M
A1	700	750	800	855	900	950	985	1065
A2	370	400	425	450	475	500	520	560
A3	425	460	490	520	550	580	600	650
A4	560	600	650	690	725	760	795	860
AL1	600	650	700	740	780	820	855	925
AL2	695	750	805	855	900	945	985	1065
KL	380	410	420	430	460	480	490	510
A5	680	750	790	820	870	870	910	960
Y1	1090	1170	1245	1325	1400	1460	1550	1660
YL1	870	1015	1105	1120	1250	1280	1360	1510

YELLOW = 4-LINE BRIDLE MODE

GREEN = 5-LINE MODE

